



*Image for reference only

DIELECTRIC WITHSTAND [HIPOT] TESTER

Model HT-20KVPac is a 20,000V Hipot Tester.

Features

- AC output: up to 20,000 V.
- Leakage current up to 5mA.
- Main shutdown switch on front panel for safety.
- Microcontroller Technology, one button test, easy to setup, LED's indicate test progress. Upon failure, buzzer sounds and testing is terminated.
- Output voltage, leakage current limit, voltage ramp-up time and test duration are controlled from the front panel.
- Voltage ramp, arc detection and test timer are defeatable.
- Separate arc detection circuitry.
- HV connector output with twist lock with a quarter turn.

- Ergonomically designed for safety, speed and efficiency.
- Designed for product development and laboratory use.
- Cables, manual and calibration certificate included.
- One year calibration cycle.
- One year warranty.

www.compwest.com

(800) 748-6224



HT-20KVP ac

FAST

SAFE

Specifications

		Voltage Test Type:	AC
		Maximum Output Voltage: Maximum Leakage Current:	0 - 20,000 Vac 5mA from 0 to 20,000V
		Input Voltage:	120 V *optional different line voltages available (100V, 110V, 220V, 230V, 240V)
		Frequency:	50/60 Hz
		Fuse:	120/230 VAC 2A/1A Slow Blow
		Breakdown Detect: Transformer Power:	Independent High Frequency Circuit < 500 VAC
		Leakage Current Detect:	Independent Low Frequency Circuit
		Ramp Time Range:	1 - 5 seconds
		Test Time Range:	1 - 60 seconds
		Discharge Timer:	<7ms
		Display:	4 Digits LED Display
		Voltage Meter Accuracy:	± 0.1KV Full Scale
		Leakage Current Accuracy:	± 0.1mA Full Scale
		Duty Cycle:	100 %
		Operation Temperature:	15 - 40 °C
		Relative Humidity Range:	0 - 90 % Non-Condensing
~	6		
	General		
		Dimensions:	17" Wide x 5.5" High x 17" Deep
		Weight:	28 lbs
		Product Package:	HT-20KVP ac
			HT-20KVP ac Product Manual
			18 AWG 4 feet Test Lead (Black)
			18 AWG 4 feet High Voltage Test Lead (Red)
			NIST Traceable Calibration Certificate to MIL-STD45662-A
	Options		
	-	(XI) Safety Interlock:	Two position terminal block on rear panel must be shorted for high voltage
			operation.
		(VF) Voltage on Failure:	If a failure stops the test, the front voltage display will hold the last voltage
		(AR) Auto Reset on Pass:	reading. Resets the HT-20KVP ac after a few seconds only on passing test condition.
		(RI) Relay Isolated Remote	It allows the interface with a PLC or other machine using relay closures. This
		Interface:	option allows isolation between the PLC and the Hipot tester.
		Zero Voltage Start:	Voltage adjust knob must be to minimum position to allow start the test cycle.
~			
	Safety		
		Visual Indicator of Voltage	Provided by front panel meter, directly connected to high voltage output.
		Output: Failure Indicator:	Audible, provided by buzzer.
			Visual, Provided by red LED's.
			Test automatically terminated on failure.
		Leakage Test:	Provided, 1mA AC factory set pass/fail point, user adjustable.

650 Gateway Center Way, Suite D. San Diego, CA 92102 USA Toll Free: (800) 748-6224 Phone: (619) 878-9696

COMPLIANCE WEST USA The blue box that tests. And tests.