SMS3000X

**User Manual** 

# scientiFic

Copyright © Scientific All rights reserved.

This instrument contains proprietary information, no part of this manual may be photocopied, reproduced or translated without any prior written consent.

Information in this manual supersedes all corresponding previous released material.

Scientific continues to improve products and reserves rights to amend part or all of the specifications, procedures, equipment at any time without notice.

Rev 1.00/ 0116

Scientific Mes-Technik Pvt. Ltd B-14 Industrial Estate, Pologround Indore - 452015 (India) Tel : 0731-2422330/31/32/33 Fax: 0731-2422334/2561641 Email : info@scientificindia.com Website : www.scientificindia.com



# Contents

General	Safety S	ummary	5
Safety T	erms and	d Symbols	.6
Spectrur	n Analyze	er overview	6
Chapter	1 Quie	ck Start	8
1.1	Appea	rance and Dimension	.9
1.2	To Pre	pare for Use	10
	1.2.1	Adjust the Supporting Legs	10
	1.2.2	Connect to AC Power Supply	11
1.3	The F	ront Panel	12
	1.3.1	Front Panel Function Keys	13
	1.3.2	Front Panel Key Backlight	14
	1.3.3	To Use the Numeric Keyboard	14
	1.3.4	Front Panel Connectors	16
1.4	Rear F	Panel	.18
1.5	User I	nterface	20
1.6	Menu	Operation	21
1.7	Param	neter Setting	23
1.8	To Use	e the Built-in Help	24
1.9	To Use	e the Security Lock	25
Chapter	2 From	nt Panel Operation	26
2.1	Basic	Settings	27
	2.1.1	Frequency	27
	2.1.2	Span	31
	2.1.3	Amplitude	32
	2.1.4	Auto Tune	36
2.2	Sweep	o and Function Settings	38
	2.2.1	BW	38
	2.2.2	Trace	39
	2.2.3	Detect	42
	2.2.4	Sweep	43
	2.2.5	Trigger	45
	2.2.6	Limit	46
	2.2.7	TG	47
	2.2.8	Demod	49
2.3	Marke	r Setup	50
	2.3.1	Marker	50
	2.3.2	Marker ->	53
	2.3.3	Marker Fn	55
	2.3.4	Peak	57
2.4	Measu	urement	59
	2.4.1	Meas	59
	2.4.2	Meas setup	60

# **Scientific**

2.5	Syster	m	66
	2.5.1	System	66
	2.5.2	Display	67
	2.5.3	File	68
2.6	Shorto	cut Key	69
	2.6.1	Preset	69
	2.6.2	Couple	72
	2.6.3	Help	
	2.6.4	Save	72
Chapter	3 Ger	neral Inspection and Troubleshooting	73
3.1	Gener	al Inspection	73
3.2	Troubl	leshooting	73
Chapter	4 Ger	neral Inspection and Troubleshooting	75

# **General Safety Summary**

Carefully read the following safety precautions to avoid any personal injury or damage to the instrument and any products connected to it. To avoid potential hazards, please use the instrument as specified.

#### Use Proper AC Power Line

Only the power cord designed for the instrument and authorized by local country should be used.

#### **Ground the Instrument**

The instrument is grounded through the protective earth conductor of the power line. To avoid electric shock, please make sure the instrument is grounded correctly before connecting its input or output terminals.

#### **Connect the Probe Correctly.**

If a probe is used, do not connect the ground lead to high voltage since it has isobaric electric potential as the ground.

#### Look Over All Terminals' Ratings

To avoid fire or electric shock, please look over all ratings and sign instruction of the instrument. Before connecting the instrument, please read the manual carefully to gain more information about the ratings.

#### **Use Proper Overvoltage Protection**

Make sure that no overvoltage (such as that caused by a thunderstorm) can reach the product, or else the operator might be exposed to danger of electrical shock. Electrostatic Prevention

Operate the instrument in an electrostatic discharge protective area environment to avoid damages induced by static discharge. Always ground both the internal and external conductors of the cable to release static before connecting.

#### **Maintain Proper Ventilation**

Inadequate ventilation may cause increasing of the instrument's temperature, which will eventually damage the instrument. So keep well ventilated and inspect the intake and fan regularly.

#### **Avoid Exposed Circuit or Components**

Do not touch exposed contacts or components when the power is on.

#### **Do Not Operate Without Covers**

Do not operate the instrument with covers or panels removed.

Use Only the Specified Fuse.

#### Keep Product Surfaces Clean and Dry.

To avoid the influence of dust and/or moisture in the air, please keep the surface of the device clean and dry.

#### Do Not Operate in Wet Conditions.

In order to avoid short circuiting to the interior of the device or electric shock, please do not operate the instrument in a humid environment.

#### Do Not Operate in an Explosive Atmosphere.

In order to avoid damage to the device or personal injury, it is important to operate the device away from an explosive atmosphere.

# Safety Terms and Symbols

Terms on the product. These terms may appear on the product:

DANGER Indicates direct injuries or hazards that may happen.
 WARNING Indicates potential injuries or hazards that may happen.
 CAUTION Indicates potential damages to the instrument or other property that may happen.

Symbols on the product. These symbols may appear on the product:



Hazardous Voltage

Protective Ground

Warning

Earth Chassis Ground

# **Spectrum Analyzer overview**

The SMS3000X series spectrum analyzer has a frequency range from 9 kHz up to 2.1 GHz/3.2 GHz, it is light weight and small size, with a user friendly interface, concise style of display, reliable precision measurement and plenty of RF measurement functions. Applicable to research and development, education, production, maintenance and other related fields, that meets a wider range of application requirements.

### **Features and Benefits**

- ♦ All-Digital IF Technology
- Frequency Range from 9 kHz up to 2.1GHz / 3.2GHz
- -161 dBm/Hz Displayed Average Noise Level (Typ.)
- -98 dBc/Hz @10 kHz Offset Phase Noise (1 GHz, Typ.)
- Total Amplitude Accuracy < 0.7 dB
- 10 Hz Minimum Resolution Bandwidth(RBW)
- Standard Preamplifier
- Up to 3.2 GHz Tracking Generator Kit (Opt.)
- Reflection Measurement Kit (Opt.)
- Advanced Measurement Kit (Opt.)
- EMI Pre-compliance Measurements Kit (Opt.)
- 10.1 inch WVGA (1024x600) Display

# Chapter 1 Quick Start

This chapter guides users to get familiar with the appearance, dimensions, front/ rear panel and the user interface, as well as announcements during first use of spectrum analyzer.

Subjects in this chapter:

- Appearance and Dimension
- To Prepare for Use
- The Front Panel
- Rear Panel
- User Interface
- Menu Operation
- Parameter Setting
- To Use the Built-in Help
- To Use the Security Lock

# **1.1 Appearance and Dimension**



Figure 1-1 Front View



Figure 1-2 Top View

# 1.2 To Prepare for Use

# 1.2.1 Adjust the Supporting Legs

Adjust the supporting legs properly to use them as stands to tilt the Spectrum Analyzer upwards for stable placement as well as easier operation and observation of the instrument.





Figure 1- 3 Before adjusting

Figure 1-4 After adjusting

# 1.2.2 Connect to AC Power Supply

The Spectrum Analyzer accept 100-240V, 50/60/440Hz AC power supply. Please use the power cord provided as accessories to connect the instrument to the power source as shown in the figure below.



Figure 1-5 Power Cord Connection

# 1.3 The Front Panel



Figure 1-6 The Front Panel

Table 1-1 Front Panel Description
-----------------------------------

NO.	Description	NO.	Description
1	User Graphical Interface	7	Numeric Keyboard
2	Menu Control Keys	8	TG Output
3	Function Keys	9	Earphone interface
4	Knob	10	USB Host
5	Arrow Keys	11	Power Switch
6	RF Input		



# 1.3.1 Front Panel Function Keys

Figure 1-7 Function Keys area

Table 1-2 Function	keys description
--------------------	------------------

Function keys	Description	
Frequency	Sets the Center Freq\Start Freq\Stop Freq\Freq Step	
Span	Sets the Span\Full Span\Zero Span\Zoom In\Zoom Out\Last Span	
Amplitude	Used to Set the REF Level\Attenuator\Preamp\Amplitude	
Auto Tune	Automatically sets the optimal parameters according to the characteristics of the signal	
BW	Used to adjust the RBW,VBW,VBW/RBW Rate, Average Type (Logpower\Power\Voltage)	
Trace	Selects Trace \Trace setup \Trace math	
Sweep	Selects the Sweep time\Sweep Rule\Sweep Mode	
Detect	Selects the Detector type	
Trigger	Used in Selecting the Free Trigger\Video Trigger/ External Trigger	
Limit	Sets the Pass\Fail Limit	
TG	Sets the TG Level\TG Level offset\Normalize	
Demod	Used to set the Parameters of the AM and FM	
Marker	Used to Select the Mark Trace and Marker math	
Marker->	Sets all types of Markers to Freq	
Marker Fn	Selects the Noise Marker\N dB BW\Freq Counter\Read out of Freq	
Peak	Searches for the Peak Signal and Counts the Peak Frequency	
Meas	Selects the Channel Power\ACPR\Occupied BW\T-Power	
Meas Setup         Used to Choose the Parameters Details of Channel Power\ACPF           BW\T-Power         BW\T-Power		

System	Selects the Language\Power on/Preset\Interface\Calibration\	
	system information\Data&Time\Self Test	
Mode	Selects the Spec Analyzer\EMI\Reflection Meas	
Display	Used to Adjust the Grid Brightness\Display Line	
File	Use to Select the File system	
Preset	Sets the system to default status	
Couple	Used to Select the RBW\VBW\Attenuator\Freq Step\Sweep time mode	
Help	Help Information Switch	
Save	Save Shortcut Key	

# 1.3.2 Front Panel Key Backlight

The on/off state and the color of the backlights of some keys at the front panel indicate the working state of the spectrum analyzer. The states are as listed below.

### 1. Power Switch 😃

- Flash on and off alternatively : indicate the unit is in stand-by state.
- Constant on: indicate the instrument is in normal operating state.

#### 2. Mode

- When the EMI or Reflection Meas function is enabled, the backlight of Mode turns on .
- When the function is **Spec Analyzer**, the backlight is turn off.
- 3. TG

When the **TG** function is enabled, the backlight of **TG** turns on and turns off when the function is disabled.

# 1.3.3 To Use the Numeric Keyboard

Spectrum Analyzer provides a numeric keyboard at the front panel (as shown in the figure below). The numeric keyboard which supports the English uppercase/lowercase characters, numbers and common symbols (including decimal point, #, space and +/-) are mainly used to edit file or folder name and set parameters (refer to "**Parameter Setting**").



Figure 1-8 Numeric Keyboard

+/-

Press this key can change the Number and letter during file or folder name editing.

- 2. 1 A/a
  - Multiplexing keys for numbers and letters. They are used to directly input the desired number or letter.
  - Press this key to input 1 in number input and switch between uppercase and lowercase letter in English input.
- 3. \* #
  - Press this key to input a decimal point in number input.
  - Press this key to input special character in English input.
- 4. Back

During the process of parameter editing, press this key to delete the character on the left of the cursor.

- 5. **Esc** 
  - During parameter editing process, press this key to clear the inputs in the active function area and exit parameter input.
  - When the instrument is in remote mode, use this key to return to local mode.
- 6. Enter

When pressed during parameter editing process, the system will complete the input and insert a default unit for the parameter automatically.

# 1.3.4 Front Panel Connectors





Figure 1-9 Front Panel Connectors

#### 1. Power Switch

Power up/Power down the instrument

#### 2. USB Host

- The analyzer can serve as a "host" device to connect external USB devices. This interface is available for USB storage devices.
- Read the 'trace' or 'state' file stored in the USB storage device, store the current instrument 'state' or 'trace' in the USB storage device or store the contents currently displayed on the screen in the USB storage device in ".bmp" format.

#### 3. Earphone Jack

The analyzer provides AM and FM demodulations. Insert the earphone to the jack to aquire the audio output of the demodulated signal. You can turn on or off the earphone output and adjust the volume via **Demod** ->**Volume**.

#### CAUTION



To protect your ears, please turn the volume down to zero and gradually turn the volume up after putting on the earphone.

#### 4. TG OUTPUT

The output of the tracking generator can be connected to a receiver through a cable with a N-type male connector.



#### CAUTION

To avoid damage to the tracking generator, the reverse DC voltage cannot exceed 50  $\ensuremath{\mathsf{V}}$ 

#### 5. RF INPUT



#### CAUTION

To avoid damage to the instrument, for the signal input from the RF input terminal, the DC voltage component and the maximum continuous power of the AC (RF) signal component can not exceed 50 V and +30 dBm respectively.

# 1.4 Rear Panel



Figure 1- 10 Rear Panel

#### 1. Handle

Pull up the handle vertically for easy carrying of the instrument. When you do not need the handle, press it down.

#### 2. USB Device interface

Connect external USB device. Through this interface, a PC can be connected to control spectrum analyzer remotely through programming or PC software.

#### 3. LAN interface

Through this interface, the analyzer can be connected to your local network for remote control.

#### 4. REF IN 10MHz

The spectrum Analyzer can use internal or external reference source.

- When a 10 MHz external clock signal is received through the [10MHz IN] connector, this signal is used as the external reference source and "Ext Ref" is displayed in the status bar of the user interface. When the external reference is lost or not connected, the instrument switches to its internal reference source automatically and "Ext Ref" on the screen disappears.
- The [10MHz IN] and [10MHz OUT] connectors are usually used to build synchronization among multiple instruments.

#### 5. REF OUT 10MHz

The spectrum Analyzer can use internal or external reference source.

- When internal reference source is used, the [10MHz OUT] connector can output a 10 MHz clock signal generated by the analyzer. This signal can be used to synchronize other instruments.
- The [10MHz OUT] and [10MHz IN] connectors are usually used to build synchronization among multiple instruments.

#### 6. Trigger in

In external trigger mode, the connector receives an external trigger signal through a BNC cable.

#### 7. Security Lock Hole

If needed, you can use a security lock (not provided with instrument) to lock the analyzer to a desired location.

#### 8. Connect to AC Power Supply

The Spectrum Analyzer accept 100-240V, 50/60/440Hz AC power supply. Please use the power cord provided as accessories to connect the instrument

# 1.5 User Interface



Table 1- 3 User Interface labels

NO.	Name	Description
1	Ref	Reference level
2	UNCAL	When the sweep time less than the auto couple time,
		the measure result may be inaccuracy, at the same
		time appear the "UNCAL"
3	Active function area	Current parameter and its value
4	EXT REF	Ext Ref
5	Att	ATT Value
6	Day and time	System time
7, 8,10	Cursor parameter	7 : current active cursor;
		8 : current cursor frequency value
		10 : current cursor amplitude value
9	Auto Tune	Automatically sets the optimal parameters according to
		the characteristics of the signal
11	USB storage device	The identification is displayed when a USB flash drive
	identification	is inserted
12	Menu title	Function of the current menu.
13	Menu items	Menu items of the current function

	- I	
14	Operation status	'Local' is local mode, 'RMT' is remote mode
15	Sweep time	Sweep time
16	Span or stop	The frequency range of the current sweep channel can
	Frequency	be expressed by the combination of center frequency
		and span or the combination of start frequency and
		stop frequency
17	Sweep progress bar	Sweep progress bar
18	Pass/Fail status	Pass/Fail status
19	VBW	Video bandwidth
20	Spectrum trace	Spectrum trace
21	RBW	Resolution bandwidth
22	Center or start	The frequency range of the current sweep channel can
	frequency	be expressed by the combination of center frequency
		or the combination of start frequency
23,24,	Trace status	Can set the trace A\B\C\D is Clear Write\Max Hold\Min
25, 26		Hold\Freeze\Average times\Math
27	AM or FM	AM or FM identification
28	PA	Enable or disable Preamplifier
29	FFT	Sweep mode is FFT
30	Single or Continue	Sweep mode single or continue
31	Average type	Log power\Power\Voltage power
32	Trigger type	Free\Video\External trigger
33, 34	Ref offset	33 : Ref offset identification;
		34 : Ref offset value
35	Scale/Div	Scale value
36	Scale type	Logarithm or linearity

# 1.6 Menu Operation

There are 7 types of menus according to their operation modes. Each type of menu and its operation method are introduced below.

### 1. Parameter Input

When selected, use the numeric keys to modify the parameters directly.



For example, select **Center Freq**, input the desired figure and press **Enter** to change the center frequency.

#### 2. state switching



Press the corresponding menu key to switch between the sub-options. For example, press **Preamp** to enable or disable the amplifier.

### Scientific

#### 3. Enter Lower Menu(with parameter)



Press the corresponding menu key to enter the lower menu and change the option currently selected. The parameter in the upper menu will change when you return to the upper menu. For example, press **Units** to enter the lower menu. Select **dBm** and return to the previous menu. The unit of Y-axis changes to dBm.

#### 4. Enter Lower Menu (without parameter)



Press the corresponding menu key to enter the lower menu. For example, press **Calibration** to enter the lower menu directly.

#### 5. Direct Execution



Press the key to execute the corresponding function. For example, press **Peak->CF** to execute a peak search and set the center frequency of the analyzer to the frequency of the current peak signal.

#### 6. Function Switch + Parameter Input



Press the corresponding menu key to switch between functions; change the parameter directly using the numeric keys.

For example, press **CF Step** to switch between **Auto** and **Manual**; if **Manual** is selected, you can directly input the desired number to change the CF Step.

#### 7. State Selection



Press the corresponding menu key to modify the parameter and return to the menu one level up.

For example, press **Trig Type** ->**Free Run** to select free trigger and the analyzer is in Free Run state at present.

# 1.7 Parameter Setting

Users can enter the desired parameter values using the numeric keys, knob or Arrow keys. This section describes the three methods of parameter setting through an example (to set the center frequency to 100 MHz).

#### 1. Use the numeric keyboard

- 1) Press Frequency-> "Center Freq"
- 2) Input **100** using the numeric keys;
- 3) Select the desired unit (MHz) from the popup menu.

#### 2. Use the knob

When the parameter is editable (namely when the parameter is selected), turn the knob clockwise to increase or counterclockwise to decrease the parameter value at the specified step.

#### 1) Press Frequency-> "Center Freq"

2) Rotate the knob until the parameter is set to the desired value (100 MHz).



Figure 1- 12 Knob

Note: In the storage function, the knob can also be used to select the current path or file.

#### 3. Use the arrow keys

When the parameter is editable (namely when the parameter is selected), you can increase or decrease the parameter value at the specific step using the direction keys.

#### 1) press Frequency -> "Center Freq"

2) Press the up/down Arrow key until the parameter is set to the desired value (100 MHz).

# 1.8 To Use the Built-in Help

The built-in help system provides information about every function key on the front panel and every menu soft key.

#### 1. How to acquire built-in help

Press **Help** and a prompt about how to obtain help information will be shown at the center of the screen. Then press the key that you want to get help of and the relevant help information will be shown at the center of the screen.

#### 2. Close the current help information

When the help information is displayed on the screen, Press the **Help** button, It will close the help information.

Help
Start Freq
Set the st Press this
The start of the grid
The span span woul
In Zero Sp are always
SCPI:
command:

Figure 1-13 help information

# **1.9 To Use the Security Lock**

If needed, you can use the security lock (not provided with instrument) to lock the Spectrum Analyzer to a fixed location. The method is as follows, align the lock with the lock hole and plug it into the lock hole vertically, turn the key clockwise to lock the Spectrum Analyzer and then pull the key out.



Figure 1-14 Security Lock

# **Chapter 2 Front Panel Operation**

This chapter describes in detail the function keys on the front panel and the associated functions.

Subjects in this chapter:

- Basic Settings
- Sweep and Function Settings
- Marker Setup
- Measurement
- System
- Shortcut Key

# 2.1 Basic Settings

# 2.1.1 Frequency

Set the frequency parameters and functions of the analyzer. Restarts sweeping every time the frequency parameters are modified.

The frequency range of a channel can be expressed by either of three groups of parameters: Start Frequency, Center Frequency and Stop Frequency. If any of the parameters is changed, the others would be adjusted automatically to ensure the coupling relationship among them

$$f_{center} = (f_{start} + f_{stop})/2$$
$$f_{span} = f_{stop} - f_{start}$$

The  $f_{span}$  is span

### 2.1.1.1 Center Frequency

Set the center frequency of the current channel. The center frequency and span values are displayed at the lower left and right sides of the grid respectively. In use process pay attention to the following points:

- The start and stop frequencies vary with the center frequency when the span is constant (except the Start Frequency and Stop Frequency to the border).
- In Zero Span mode, the start frequency, stop frequency and center frequency are always the same.

Parameter	Explanation		
Default	Full Span/2		
Range	Zero Span, 0 Hz ~ Full Span Nonzero Span, 50 Hz ~ (Full Span -50Hz)		
Unit	GHz\MHz\kHz\Hz		
Knob Step	Span>0, step=Span/200		
	Span=0, step=RBW/100		
	Min 1 Hz		
Direction Key Step	CF step		
Related to	Start Freq, Stop Freq		

Table 2-1	Center Frequency	/
	ounter i requeriej	

## 2.1.1.2 Start Frequency

Set the start frequency of the current channel. The start and stop frequencies are displayed at the lower right sides of the grid respectively. In use process pay attention to the following points:

The span and center frequency vary with the start frequency when the Span did not reach the minimum (The parameters vary with the span, please refer to "Span"), In Zero Span mode, the start frequency, stop frequency and center frequency are always the same.

	- 1
Parameter	Explanation
Default	0 GHz
Range	Zero Span, 0 Hz ~ Full Span
	Nonzero Span, 0 Hz ~ (Full Span-100Hz
Unit	GHz\MHz\kHz\Hz
Knob Step	Span>0, step=Span/200
	Span=0, step=RBW/100
	Min 1 Hz
Direction Key Step	CF step
Related to	Center Freq, Span

Table 2-2 Start Frequency

# 2.1.1.3 Stop Frequency

Set the stop frequency of the current channel. The start and stop frequencies are displayed at the lower right sides of the grid respectively. In use process pay attention to the following points:

- The span and center frequency vary with the stop frequency. The change of span would affect other system parameters. For more details, please refer to "Span".
- In Zero Span mode, the start frequency, stop frequency and center frequency are always the same.

Parameter	Explanation
Default	Full Span
Range	Zero Span: 0 Hz ~ Full Span
	Nonzero Span: 100 Hz ~ Full Span
Unit	GHz\MHz\kHz\Hz
Knob Step	Span>0, step=Span/200
	Span=0, step=RBW/100
	Min 1 Hz
Direction Key Step	CF step
Related to	Center Freq, Span

 Table 2- 3
 Stop Frequency

### 2.1.1.4 Freq Step

Arrow key step of the center frequency. start frequency and stop frequency vary with the stop frequency. In use process pay attention to the following points :

- At a fixed step change the value of the center frequency can reach the purpose of continuous measurement channel switch.
- There are two kinds of frequency step mode : Auto and manual. In Auto mode, the CF step is 1/10 of the span in Non-zero span mode or equals the RBW while in Zero span mode; in Manual mode; you can set the step using the numeric keys.

Parameter	Explanation
Default	Full Span/10
Range	1Hz ~ Full Span
Unit	GHz,MHz,kHz,Hz
Knob Step	Span>0, Step=Span/200
	Span=0,
	Step=100 min 1
Direction Key Step	1-2-5 sequence step
Relation	RBW, Span and related parameters

#### Table 2- 4 Frequency step

### 2.1.1.5 Peak -> CF

Execute a peak search and use the frequency of the current peak as the center frequency (CF) of the analyzer. The function is invalid in Zero Span mode.

### **Scientific**



Figure 2-1 Before Peak -> CF



Figure 2- 2 After peak -> CF

### 2.1.1.6 CF -> Step

Set the current center frequency as the CF step. At this point, the CF step will switch to "Manual" mode automatically. This function is usually used with channel switching. Take harmonic waveform measurement for example: locate a signal at the center frequency of a channel, execute CF->Step and then press the down direction key continuously to measure each order of harmonic in sequence

# 2.1.2 Span

Set the span of the analyzer. The change of this parameter will affect the frequency parameters and restart the sweep.

### 2.1.2.1 Span

Set the frequency range of the current channel. Press this key to switch to center frequency/span input mode .The center frequency and span are displayed at the low left and right sides of the grid respectively. In use process pay attention to the following points :

- The start and stop frequency vary with the span when the center frequency is constant.
- In manual span mode. The span can be set down to 100Hz and up to the full span described in Specifications. When the span is set to the maximum, the analyzer enters full span mode.
- Modifying the span in non-zero span mode may cause an automatic change in both CF step and RBW if they are in Auto mode. Besides, the charge of RBW may influence VBW (in Auto VBW mode).
- Variation in the span, RBW or VBW would cause a change in the sweep time.
- ◆ In non-zero span mode, neither "Video" trigger nor "1/△time" readout function is valid.
- You can modify this parameter using the numeric keys, knob or direction keys, For more details, please refer to "Parameter Setting".

Parameter	Explanation
Default	Maximum bandwidth
Range	0 Hz to 2.1/3.2GHz
Unit	GHz,MHz,kHz,Hz
Knob Step	Span/200, Min = 1 Hz
Direction Key Step	In 1-2-5 sequence
Related to	Start Freq, Stop Freq, Freq Step, RBW, Sweep time

Table 2-5 Span

Note: 0 Hz is available only in zero span.

### 2.1.2.2 Full Span

Set the span of the analyzer to the maximum.

### 2.1.2.3 Zero Span

Set the span of the analyzer to 0Hz. Both the start and stop frequencies will equal the center frequency and the horizontal axis will denote time. The analyzer measures the time domain characteristics of the amplitude of the corresponding frequency point on the input signal. In use process pay attention to the following points:

The following functions are invalid in Zero span mode: Peak ->CF, Signal Track, Zoom In, Zoom Out.

- ♦ Frequency: Peak->CF;
- SPAN: Zoom In and Zoom Out;
- ◆ Marker-> : M ->CF, M->CF step, M->Start Freq, M->Stop Freq, △M->CF and △M->Span;
- ◆ Marker: Frequency, Period and 1/△Time(valid in Delta marker type);

# 2.1.2.4 Zoom In

Set the span to half of its current value. At this point, the signal on the screen is zoomed in to observe signal details.

### 2.1.2.5 Zoom Out

Set the span to twice the current value. At this point, the signal on the screen is zoomed out to gain more information about the signal.

### 2.1.2.6 Last Span

Set the span to the previous span setting.

# 2.1.3 Amplitude

Set the amplitude parameters of the analyzer. Through modifying these parameters, signals under measurement can be displayed in a proper mode for easier observation and minimum error.

### 2.1.3.1 Ref Level

Set the maximum power or voltage that can be currently displayed in the window. The value is displayed at the upper left corner of the screen grid.

The maximum reference level available is affected by the maximum mixing level, input attenuation is adjusted under a constant maximum mixing level in order to fulfill the following condition:

```
LRef <= aRF-aPA-30dBm
```

SMS3000X

Parameter	Explanation
Default	0 dBm
Range	-100dBm to 30dBm
Unit	dBm, mV, uV
Knob Step	In Log scale mode, step = Scale/10
	In Lin scale mode, step=0.1 dBm
Direction Key Step	In Log scale mode, step = Scale
	In Lin scale mode, step=1 dBm
Related to	Attenuator, Preamp, Ref Offset

Table 2	2-6	Ref	Level

### 2.1.3.2 Attenuator

Set the front attenuator of the RF input in order to ensure big signals (or small signals) to pass through the mixer with low distortion(or low noise).

LRef <= aRF-aPA-30dBm

Input attenuation can be set up for automatic and manual two kinds of patterns.

- Automatic mode attenuation value according to the state of preamplifier and value of the current reference level automatic adjustment.
- Open the preamplifier, maximum input attenuation can be set to 51db. When setting parameters do not meet the above formula, can adjust the reference level.
- You can modify this parameter using the numeric keys, knob or direction keys. For more details, please refer to "Parameter Setting.

Parameter	Explanation
Default	Explanation
Range	10 dB
Unit	0 to 51 dB
Knob Step	1 dB
Direction Key Step	Scale/Div
Related to	Preamp, Ref level

Table 2- 7 Attenuator	Table	2-7	'Atter	nuator
-----------------------	-------	-----	--------	--------

### 2.1.3.3 RF Preamp

Turn on or off the preamplifier located at the front of the RF signal path. When signal under measurement is small, turning on the preamplifier can reduce the displayed noise level; there for, you can distinguish small signals from the noise.

• The corresponding icon "PA" will be appear at the left side of the screen when the preamplifier is turned on.

# 2.1.3.4 Units

Set the unit of the Y-axis to dBm, dBmV, dBuV, Volts and Watts. The default is dBm $_{\circ}$ 

• The conversion relationships between units are as follows.

$$dBm = 10log\left(\frac{Volts^{2}}{R} \times \frac{1}{0.001W}\right)$$
$$dBV = 20log\left(\frac{Volts \times 10^{6}}{1uV}\right)$$
$$dBmV = 20log\left(\frac{Volts \times 10^{3}}{1mV}\right)$$
$$Watts = \frac{Volts^{2}}{R}$$

Wherein, R denotes the reference resistance. Value is  $50 \Omega$ 

# 2.1.3.5 Scale

Set the logarithmic units per vertical grid division on the display. This function is only available when the scale type is set to "log". In use process pay attention to the following points:

- By changing the scale, the amplitude range available is adjusted.
- The range of the amplitude that can be displayed
- Minimum: reference level  $-10 \times$  the current scale value;
- Maximum: the reference level.
- You can modify this parameter using the numeric keys, knob or direction keys. For more details, please refer to "Parameter Setting".

Parameter	Explanation
Default	10 dB
Range	0.5 to 10dB
Unit	dB
Knob Step	Scale≥1, Step=1 dB
	Scale<1, Step=0.1
Direction Key Step	Scale≥1, 1-2-5 sequence
Related to	Scale Type

Table 2- 8 Scale

## 2.1.3.6 Scale Type

Set the scale type of Y-axis to Lin or Log. The default is Log.

In Lin mode, Scale value cannot be changed. Display area for reference level of 0%. In use process pay attention to the following points:

- In Log scale type, the Y-axis denotes the logarithmic coordinate; the value shown at the top of the grid is the reference level and each grid represents the scale value. The unit of Y-axis will automatically switch to the default unit (dBm) in Log scale type is changed from Lin to Log.
- In Lin scale type, the Y-axis denotes the liner coordinate; the values shown at the top of the grid and the bottom of the grid are the reference level and the scale setting function is invalid. The unit of Y-axis will automatically switch to the default unit(Volts) in Lin scale type when the scale type is charged from Log to Lin.

### 2.1.3.7 Ref Offset

Assign an offset to the reference level to compensate for gains or losses generated between the device under measurement and the analyzer.

- The change of this value changes both the reference level readout and the amplitude readout of the marker; but does not impact the position of the curve on the screen.
- You can modify this parameter using the numeric keys. For more details, please refer to "Parameter Setting".

Parameter	Explanation
Default	0 dBm
Range	-100~ 100dBm
Unit	dBm
Knob Step	1 dBm
Direction Key Step	10dBm

#### Table 2- 9 Ref Offset

### 2.1.3.8 Correction

Correct the amplitude in order to compensate for the gain or loss from external devices such as Antenna and Cable. When using this function, you can view the correction data table and save or load the current correction data. When amplitude correction is turn on, both the trace and related measurement results will be corrected.

1. Select

Select a correction factor from Antenna, Cable, Other and User for the current correction and the default is Off(turn off all the correction factors). After choosing the desired correction factors, press "Correction" to enable the correction factors selected. Multiple correction factors can be enabled at the same time.

2. Correction

Enable or disable amplitude correction and the default is Off. When amplitude correction is enabled, the data of the correction factor currently selected is used for amplitude correction. If multiple factors are enabled, all related data will be used for amplitude correction.

# 2.1.4 Auto Tune

Search for signals automatically throughout the full frequency range; adjust the frequency and amplitude for optimum display effect of the signal to realize one-key signal search and auto setting of parameters.

- In the process of auto search, The "Auto Tune" is shown in the status bar on the screen until the search is finished.
- Some parameters such as the reference level, scale, input attenuation and maximum mixing level may be changed during the auto search.

<b>Ref</b> 0.00 dBm	Att 20.00	dB			
Center Fre	quency				
<sub>-20</sub> 1.600000	00 GHz				
-30					
-40					
-50	ار بالمعان من من المعان م	y is a month the product	We will all a south the first line	working the second state of the second states of th	hy why have have
-60 WWWWWWWWWWWW	www.hallanananananananananananananananananan	Periodian and a second second second	ala native a character a		
-70					
-80					
-90					
-100					
Center 1.600000000 RBW 3.000000		<b>VBW</b> 3.000000	MH2	Stop 3.20 SWT	0000000 GHz 120.160 ms

Figure 2-3 Before Auto Tune


Figure 2-4 After Auto Tune

# 2.2 Sweep and Function Settings

## 2.2.1 BW

Set the RBW (Resolution Bandwidth), VBW (Video Bandwidth) and average type parameters of the analyzer.

## 2.2.1.1 Resolution Bandwidth

Set the desired resolution bandwidth in order to distinguish between signals which are close in frequency.

Key Points:

- Reducing RBW will increase the frequency resolution, but will increase the sweep time (Sweep Time is affected by a combination of RBW and VBW when it is in Auto mode).
- RBW varies with the span (non-zero span) in Auto RBW mode.

Table	2-1	10 F	BW	
_				

Parameter	Explanation
Default	1MHz
Range	10Hz ~ 1MHz
Unit	MHz,kHz,Hz
Knob Step	in 1, 3, 10 sequence
Direction Key Step	in 1, 3, 10 sequence
Relation	Span,RBW,VBW,Sweep Time

## 2.2.1.2 Video Bandwidth

Set the desired video bandwidth in order to filter out the noise outside the video band. : Key Points:

- Reducing the VBW will smooth the spectrum line to highlight small signals from noise, but will increase the sweep time (Sweep Time is affected by a combination of RBW and VBW when it is in Auto mode).
- VBW varies with RBW when it is set to Auto. While in Manual mode, VBW is not affected by RBW.

Parameter	Explanation
Default	1MHz
Range	1Hz ~ 3MHz
Unit	MHz,kHz,Hz
Knob Step	in 1, 3, 10 sequence
Direction Key Step	in 1, 3, 10 sequence
Relation	RBW,V/R Ratio,Sweep Time

## 2.2.1.3 V/R Ratio

Set the ratio of VBW to RBW. This value is different while measuring different kinds of signals:

- Sine signal: use 1 to 3 (for faster sweeps)
- Pulse signal: use 10 (to reduce the influence on the amplitude of transient signals)
- Noise signal: generally use 0.1 (to obtain the average of noises)

Parameter	Explanation	
Default	1	
Range	0.001 ~ 1000	
Unit	N/A	
Knob Step	in 1, 3, 10 sequence	
Direction Key Step	in 1, 3, 10 sequence	
Relation	RBW VBW	

Table 2- 12 V/R Ratio

## 2.2.1.4 Average Type

Chooses one of the following averaging type: log power (video), power (RMS), or voltage averaging. When trace average is on, the average type is shown on the left side of the display.

#### 1. Log Power

Selects the logarithmic (decibel) scale for all filtering and averaging processes. This scale is "Video" because it is the most common display and analysis scale for the video signal within a spectrum analyzer. This scale is excellent for finding CW signals near noise.

#### 2. Power Average

In this average type, all filtering and averaging processes work on the power(the square of the magnitude) of the signal, instead of its log or envelope voltage. This scale is best for measuring the true time power of complex signals.

#### 3. Voltage Average

In this Average type, all filtering and averaging processes work on the voltage of the envelope of the signal. This scale is good for observing rise and fall behavior of AM or pulse-modulated signals such as radar and TDMA transmitters.

## 2.2.2 Trace

The sweep signal is displayed as a trace on the screen.

## 2.2.2.1 Select Trace

Spectrum Analyzer allows for up to four traces to be displayed at the same time. Each trace has its own color (Trace 1 - Yellow, Trace 2 - Purple, Trace 3 - Light blue and Trace 4 - Green). All traces can be set parameter independently. As a default, spectrum analyzer will choose Trace A and set the type of the trace as Clear Write

## 2.2.2.2 Trace Type

Set the type of the current trace or disable it. The system calculates the sampled data using a specific operation method according to the trace type selected and displays the result. Trace types include Clear Write, Max Hold, Min Hold, View, Average and Bank. The corresponding icon of the trace type will be displayed in the status bar at the left of the screen. Take Trace 1,2,3,4 as an example and the icons are as shown in the figure below.



Figure 2- 5 Trace Type

#### 1. Clear Write

Erases any data previously stored in the selected trace, and display the data sampled in real-time of each point on the trace.

#### 2. Max Hold

Retains the maximum level for each trace point of the selected trace. Updates the data if a new maximum level is detected in successive sweeps.

#### 3. Min Hold

Display the minimum from multiple sweeps for each point of the trace and update the data if a new minimum is generated in successive sweeps.

#### 4. View

Holds and displays the amplitude data of the selected trace. The trace data is not updated as the analyzer sweeps.

#### 5. Bank

Disable the trace display and all measurements of this trace.

## 2.2.2.3 Average Times

Set the number of averages of the selected trace. Key Points:

More averages can reduce the noise and the influence of other random signals; thus highlighting the stable signal characteristics. The larger the number of averages is, the smoother the trace will be.

Parameter	Explanation
Default	100
Range	1 ~ 999
Unit	N/A
Knob Step	N/A
Direction Key Step	N/A

Table 2- 13 Average Times

## 2.2.2.4 Math

Set the computational method of the math trace.

1. Variable X,Y

Variable X,Y can be A, B, C.

2. Const

Set the value of the constant.

Table 2- 14 Const

Parameter	Explanation
Default	0dB
Range	-300 dB ~ 300 dB
Unit	dB

3. Output Z

The result Z will shown on screen in trace A,B,C as you choose.

#### 4. Calculation Type

Spectrum Analyzer provides the calculation types as shown below:

X-Y+Ref $\rightarrow$ Z Y-X+Ref $\rightarrow$ Z X+Y-Ref $\rightarrow$ Z X+const $\rightarrow$ Z X-const $\rightarrow$ Z

## 2.2.3 Detect

## 2.2.3.1 Detect Type

The analyzer displays the sweep signal on the screen in the form of trace. For each trace point, the analyzer always captures all the data within a specific time interval and processes (Peak, Average, etc.) the capture data using the detector currently selected, then display the processed data (one point) on the screen .

Key Points:

- Select an appropriate detector type according to the actual application in order to ensure the accuracy of the measurement.
- The available types are Pos Peak, Neg Peak, Sample, Normal, Average. The default is Pos peak.

#### **Positive Peak**

For each trace point, Positive Peak detector displays the maximum value of data sampled within the corresponding time interval.

#### **Negative Peak**

For each trace point, Negative Peak detector displays the minimum value of data sampled within the corresponding time interval.

#### Sample

For each trace point, Sample detector displays the transient level corresponding to the central time point of the corresponding time interval. This detector type is applicable to noise or noise-like signal.

#### Normal

Normal detector (also called rosenfell detector) displays the maximum value and the minimum value of the sample data segment in turn; namely for an odd-numbered data point, the maximum value is displayed; for an even-numbered data point, the minimum value is displayed. In this way, the amplitude variation range of the signal is clearly shown.

#### Average

For each trace point, Average detector displays the average value of data sampled within the corresponding time interval.

## 2.2.4 Sweep

Set parameters about the Sweep functions, including sweep time, sweep rule, sweep mode, number of sweep, etc.

## 2.2.4.1 Sweep Time

Set the time needed for the spectrum analyzer to finish a sweep within the span range. The sweep time can be set in "Auto" or "Manual" mode and the default is "Auto".

Key Points:

- In non-zero span, the analyzer selects the shortest sweep time on the basis of the current RBW and VBW settings if Auto is selected.
- Decreasing the sweep time would speed the measurement. However, an error may be caused if the specified sweep time is less than the minimum sweep time in Auto coupling; at this point, "UNCAL" is shown in the status bar on the screen

Parameter	Explanation	
Default	50ms	
Range	917us ~ 3000 s	
Unit	ks,s,ms,us,ns	
Knob Step	Sweep time/100, min =1 ms	
Direction Key Step	in 1,3 sequence	

Table 2- 15 Sweep Time

## 2.2.4.2 Sweep Rule

The analyzer provides two sweep time rules to meet the different sweep time requirements: Speed: Activates the default fast sweep time rule.

Accuracy: Activates the normal sweep time rule to ensure the measurement accuracy.

Speed sweep time rule provides a fast measurement function that decreases the sweep time. Using Fast Sweep will decrease the measurement accuracy.

## 2.2.4.3 Sweep

Set sweep mode in single or continuous, the default is continuous. The corresponding icon of the sweep will be displayed in the status bar at the left of the screen.

## Single

### 1. Single

Set the sweep mode to "Single". The number on the parameter icon denotes the current sweep number.

### 2. Numbers

Set the number of sweeps for a single sweep. In single sweep mode, the system executes the specified number of sweeps and the number shown on the icon in the status bar at the left of the screen varies with the process of the sweep.

#### Continue

Set the sweep mode to "Continue". The character Cont on the parameter icon denotes the analyzer is sweeping continuously.

Key Points:

- If the instrument is in single sweep mode and no measurement function is enabled, press this key and the system will enter continuous sweep mode and sweep continuously if the trigger conditions are satisfied.
- If the instrument is in single sweep mode and a measurement function is on, press this key and the system will enter continuous sweep mode and measure continuously if the trigger conditions are satisfied.
- In continuous sweep mode, the system will send a trigger initialization signal automatically and enter the trigger condition judgment directly after each sweep.

Table	2-	16	Sweep	Times
iubic	<u> </u>	10	Owcep	111100

Parameter	Explanation
Default	1
Range	1 ~ 9999
Unit	N/A
Knob Step	1
Direction Key Step	1

### 2.2.4.4 Sweep Mode

Sweep mode includes auto, sweep and FFT.

- Auto Mode : When the sweep mode is auto-coupled, the analyzer selects the sweep mode automatically between Sweep and FFT Mode.
- **Sweep Mode** : Work in point-by-point scanning, slow and time-consuming, fits when RBW is more than 10kHz.
- **FFT Mode** Work in Parallel scans, fast and short time. This FFT mode is only available when RBW is set to 1 kHz, 3 kHz, or 10 kHz.

## 2.2.5 Trigger

The trigger type can be Free Run, Video or External.

## 2.2.5.1 Free Run

The trigger conditions are satisfied at any time and the analyzer generates trigger signals continuously.

## 2.2.5.2 Video

A trigger signal will be generated when the system detects a video signal of which the voltage exceeds the specified video trigger level.

Note: This function is invalid in Avg detection in zero span mode.

#### Trigger level

Set the trigger level in video trigger. At this point, the trigger level line (TL) and value are displayed on the screen. You can use the numeric keys, knob or direction keys to modify this parameter. Please refer to "Parameter Setting" for more details.

Parameter	Explanation
Default	0 dBm
Range	-200 dBm ~ 50 dBm
Unit	dBm
Knob Step	1 dBm
Direction Key Step	10 dBm

#### Table 2- 17 Trigger Setup

### 2.2.5.3 External

In this mode, an external signal (TTL signal) is input from the [TRIGGER IN] connector at the rear panel and trigger signals are generated when this signal fulfills the specified trigger edge condition.

Set the trigger edge in external trigger to the rising (Pos) or falling (Neg) edge of the pulse. **Note:** When "Free Run" is selected, **Trig Setup** is grayed out and disabled.

## 2.2.6 Limit

Spectrum Analyzer supports the Pass/Fail test function. In this function, the measured curve is compared with the pre-edited curve. If the related rules are met, the result is "Pass"; or else is "Fail".

## 2.2.6.1 Limit Switch

Select the desired limit line (upper or lower) for editing. Each limit line has its own switch. You can test according to both together, either one or neither.

## 2.2.6.2 Edit

Edit the properties of the limit lines.

#### Table 2- 18 Pass/Fail Menu

Function	Explanation
Upper/Lower	Select the desired limit line (upper or lower) for editing
Mode	Select the line or point for editing. Set the number of the point to be edited if you selected the point type. The range is from 1 to 100
Add point	Add a new point for editing.
X-axis	Edit the X-axis value (frequency or time) of the current point. If the X-axis unit is frequency and the Ref Freq is enabled, edit the frequency difference between the
Amplitude	Edit the amplitude of the current point or line. If the Ref AMPT is enabled, edit the amplitude difference between the amplitude of the current point and the reference
Del Point	Delete the point you are editing.
Del All	Delete all point.
Save/Recall	Save or load the limit file.

### 2.2.6.3 Test

Start or Stop the limit test function.

## 2.2.6.4 Setup

#### Fail to stop

Select whether the instrument will continue or stop operation when a failure occurs.

#### Buzzer

Turn on or off the buzzer. When the buzzer is on, it beeps when a failure occurs.

### X Axis

Set the X-axis unit to frequency or time unit.

Note that all the points of the current limit line will be deleted when the X-axis unit changes.

## 2.2.7 TG

Set the parameter related to the tracking generator (TG).

## 2.2.7.1 TG

**TG** is used to enable or disable the TG. When the TG is enabled, a signal with the same frequency of the current sweep signal will be output from the **[GEN OUTPUT 50Ω]** connector at the front panel. The power of the signal could be set through the menu.

## 2.2.7.2 TG Level

Set the output power of the signal of the tracking generator. You can use the numeric keys, knob or direction keys to modify this parameter. For more details, please refer to "**Parameter Setting**".

Parameter	Explanation
Default	0 dB
Range	-200 dB ~ 200 dB
Unit	dB
Knob Step	1 dB
Direction Key Step	10 dB

## 2.2.7.3 TG Level Offset

Assign a certain offset to the output power of the TG when gains or losses occur between the TG output and external device in order to display the actual power value.

#### **Key Points:**

- This parameter only changes the readout of the TG output power, rather than the actual value of it.
- The offset could be either a positive (gain in the external output) or a negative (loss in the external output).
- You can use the numeric keys, knob or direction keys to modify this parameter. For more details, please refer to "Parameter Setting".

Parameter	Explanation
Default	0 dB
Range	-200 dB ~ 200 dB
Unit	dB
Knob Step	1 dB
Direction Key Step	10 dB

#### Table 2- 20 TG Level Offset

## 2.2.7.4 Normalize

Normalization can eliminate the error of TG Level. Before using this function, connect the **[GEN OUTPUT 50\Omega]** output terminal of the TG with the **[RF INPUT 50\Omega]** input terminal of the analyzer.

#### 1. Normalize

Enable or disable the normalization. When enabled, the reference trace will be stored automatically after the current sweep finishes if no reference trace is stored before. During the reference trace storage, the corresponding prompt message is displayed. When normalization is enabled, the corresponding value of the reference trace will be subtracted from the trace data after every sweep.

#### 2. Norm Ref Lvl

Adjust the vertical position of the trace on the screen by adjusting the reference level when normalization is enabled.

Being different from the **Ref Level** function in the **AMPT** menu, this parameter has no influence on the reference level of the analyzer.

You can use the numeric keys, knob or direction keys to modify this parameter. For more details, please refer to "**Parameter Setting**".

Parameter	Explanation
Default	0 dB
Range	-200 dB ~ 200 dB
Unit	dB
Knob Step	1 dB
Direction Key Step	10 dB

Table 2-21 Reference level under normalization

#### 2. Norm Ref Pos

Adjust the vertical position of the normalization reference level on the screen by adjusting the reference position when normalization is enabled.

- The function of this menu is similar to that of Norm Ref LvI. When it is set to 0%, the normalization reference level is displayed at the bottom of the screen grid and at the top when it is set to 100%.
- You can use the numeric keys, knob or direction keys to modify this parameter. For more details, please refer to "Parameter Setting".

Parameter	Explanation	
Default	100%	
Range	0 ~ 100%	
Unit	100%	
Knob Step	1%	
Direction Key Step	10%	

Table 2- 22 TG reference posi	tion
-------------------------------	------

#### 3. Ref Trace

Set whether to display the reference trace or not. If "View" is selected, the reference trace saved (Trace D) will be shown in "FreezeView" type.

**Note:** When normalization is enabled, the unit of Y-axis is "dB" and will not be influenced by the definition in **AMPT->Units**. At this point, "(dB)" is displayed under the Y-axis scale in the user interface.

## 2.2.8 Demod

Press **Demod** at the front panel to enter the demodulation setting menu. Both AM and FM demodulations are available in this device.

### 2.2.8.1 Demod (AM/FM)

Set the demodulation type to AM or FM; or disable the demodulation function. The default is off. **Key Points:** 

- The system will enable a marker automatically, place it at the center frequency and perform AM (or FM) demodulation on this frequency point after you enable AM (or FM) demodulation.
- Analyzer provides earphone jack and the demodulated signal can be output in audio frequency (AF) mode through the earphone. The frequency and intensity of AF denotes the frequency and amplitude of the signal respectively.

### 2.2.8.2 Earphone

Set the status of the earphone. When it is on, the demodulated signal can be heard through the earphone during the demodulation. By default, it is off.

### 2.2.8.3 Volume

Set the volume of the earphone.

Table	2-	23	Volume
-------	----	----	--------

Parameter	Explanation
Default	6
Range	0 ~ 10
Unit	N/A
Knob Step	1
Direction Key Step	1

## 2.2.8.4 Demod Time

Set the time for the analyzer to complete a signal demodulation after each sweep. If **Earphone** is set to "On", you will hear the demodulated signal through the earphone during the demodulation. You can use the numeric keys, knob or direction keys to modify this parameter. For more details, please refer to "**Parameter Setting**".

## **Scientific**

Table 2- 24 Demod time			
Parameter	Explanation		
Default	5ms		
Range	5ms ~ 1000s		
Unit	ks,s,ms		
Knob Step	0 ms ~ 100 ms, step=1 ms ;		
	100 ms ~ 1 s, step =10 ms ;		
	1 s ~ 10 s, step =100 ms ;		
	10 s ~ 100 s, step =1 s ;		
	100 s ~ 1000 s, step =10 s		
Direction Key Step	1-2-5 step		

# 2.3 Marker Setup

## 2.3.1 Marker

The marker appears as a rhombic sign (as shown below) for identifying the point on the trace. You can easily read the amplitude, frequency and sweep time of the marked point on the trace.

## Key Points:

- The analyzer allows for up to four pairs of markers to be displayed at one time, but only one pair or a single marker is active every time.
- You can use the numeric keys, knob or direction keys to modify the desired frequency or time as well as view the readouts of different points on the trace.



Figure 2-6 Marker

## 2.3.1.1 Select Marker

Select one of the four markers and the default is Marker1. When a marker is selected, you can set its type, trace to be marked, readout type and other related parameters. The enabled marker will appear on the trace selected through the **Select Trace** option and the readouts of this marker are also displayed in the active function area and at the upper right corner of the screen.

Parameter	Explanation
Default	Center Frequency
Range	0 ~ Full Span
Unit	Readout = Frequency (or Period), units available are GHz, MHz, kHz, Hz (or s, ms,
	us, ns, ps)
	Readout = Time, units available are s, ms, us, ns, ps
Knob Step	Readout = Frequency (or Period), Step = Span/(Sweep Points - 1)
	Readout = Time, Step = Sweep Time/(Sweep Points - 1)
Direction	Readout = Frequency (or Period), Step = Span/10
Key Step	Readout = Time, Step = Sweep Time /10

Table 2- 25 Marker parameters

## 2.3.1.2 Select Trace

Select the trace to be marked by the current marker from A,B,C,D.

## 2.3.1.3 Normal

One of the marker types. It is used to measure the X (Frequency or Time) and Y (Amplitude) values of a certain point on the trace. When selected, a marker with the number of the current marker (such as "1") appears on the trace.

Key Points:

- If no active marker exists currently, a marker will be enabled automatically at the center frequency of the current trace.
- You can use the numeric keys, knob or direction keys to move the marker. The readouts of the marker will be displayed at the upper right corner of the screen.
- The readout resolution of the X-axis (frequency or time) is related to the span. For higher readout resolution, reduce the span.

## 2.3.1.4 Delta

One of the marker types. It is used to measure the delta values of X (Frequency or Time) and Y (Amplitude) between the reference point and a certain point on the trace. When selected, a pair of markers appears on the trace: Reference Marker (marked by a combination of the marker number and letter "R", such as "1R") and the Delta Marker (marked by the marker number, such as "1").

• A reference marker will be activated at the position of the current marker if an active marker currently exists; or else both the reference marker and delta marker will be simultaneously activated at the center frequency.

- The location of the reference marker is always fixed (both on the X-axis and the Y-axis); while the Delta Marker is active. You can use the numeric keys, knob or direction keys to change the location of the Delta Marker.
- The frequency (or time) delta and amplitude delta between the two markers are displayed at the upper right corner of the screen.
- There are two methods for defining a point as the reference point:
- a) Open a "Normal" marker and locate it onto a point. Then, switch the marker type to "Delta"; at this time, this point is the reference point. You can modify the location of the delta point to achieve delta measurement.
- b) Open a "Delta" marker and locate it onto a point. Then, reselect the Delta menu to locate the reference marker onto this point. You can modify the location of the delta point to achieve delta measurement.
- When the Noise Marker function under the Marker Fn menu is activated, the result of the noise measurement will be corrected automatically and be normalized to 1 Hz.

#### The application of "Delta" marker

Measure the signal-noise ratio of single spectrum signal: Place the reference and delta Markers onto the signal and noise respectively, the amplitude in the measurement result is the signal-noise ratio.

## 2.3.1.5 Delta Pair

One of the marker types. When selected, a pair of markers will appear on the trace: Reference Marker (marked by a combination of the marker number and letter "R", such as "1R") and the Delta Marker (marked by the marker number, such as "1").

#### Key Points:

- You can use the numeric keys, knob or direction keys to set the locations of the reference marker (selecting "Ref"), the delta marker (selecting "Delta"), the span of marker pair(selecting "Span") and the center of marker pair(selecting "Center") respectively.
- This is different from the Delta type marker in that you can modify both the reference (selecting "Ref") and delta (selecting "Delta") points or modify both them at the same time(selecting "Span" or "Center"). Additionally, both the X and Y values of the reference marker are stable for "Delta" marker during the sweep; but the Y value of the reference marker updates along with the sweep for "Delta Pair" marker
- If "Span" is selected, setting the "Span Pair" will keep the center position of the two markers unchanged and move them towards the two sides (value increases) or the middle (value decreases).
- If "Center" is selected, setting the "Span Pair" will keep the relative distance between the two markers unchanged and move their center position left (value decreases) or right (value increases).

### 2.3.1.6 Relative To

Relative to is used to measure the delta values of X (Frequency or Time) and Y (Amplitude) between two markers which mark on different traces.

## 2.3.1.7 Off

Turn off the marker currently selected. The marker information displayed on the screen and functions based on the marker will also be turned off.

## 2.3.1.8 Marker Table

Enable or disable the Marker Table.

Display all the markers enabled on the lower portion of the screen, including marker number, trace number, marker readout type, X-axis readout and amplitude. Through this table you can view the measurement values of multiple points. The table allows for up to eight markers to be displayed at one time.

<b>Ref</b> -13.00 dBm		Att 10.00 dB	Att 10.00 dB ▲ Marker1		-0.01 dB
20					
<sup>27</sup> Marl	ker Delta	11	1		
	66667 MHz	1			
	1 dB	2/	12		
55		/			
62		34	3		
69		4r /		4	
76				~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	
	.000000 MHz .000000 MHz able	VBW 1	000000 MHz	Span SWT	20.000000 MH 24.032 m
Marker	Trace	Readout	X Axis	Ampt	
ΔM1	A	Frequency	2.133333 MHz	-0.01 dB	
1R	A	Frequency	48.933334 MHz	-35.89 dBm	
ΔM2	А	Frequency	2.933334 MHz	0.05 dB	
2R	А	Frequency	48.533333 MHz	-48.26 dBm	
⊿МЗ	А	Frequency	3.733334 MHz	0.30 dB	
ЗR	А	Frequency	48.133333 MHz	-64.84 dBm	
ΔM4	A	Frequency	8.000000 MHz	-0.07 dB	
4R	A	Frequency	46.000000 MHz	-74.82 dBm	

Figure 2-7 Marker table

## 2.3.2 Marker ->

### 2.3.2.1 M->CF

Set the center frequency of the analyzer to the frequency of the current marker.

- If Normal marker is selected, the center frequency will be set to the frequency of the current marker.
- If Delta, or Delta Pair marker is selected, the center frequency will be set to the frequency of the Delta Marker.
- The function is invalid in Zero span mode.

## 2.3.2.2 M -> CF Step

Set the center frequency step of the analyzer to the frequency of the current marker.

- If **Normal** marker is selected, the center frequency step will be set to the frequency of the current marker.
- If Delta, or Delta Pair marker is selected, the center frequency step will be set to the frequency of the Delta Marker.
- The function is invalid in Zero span mode.

## 2.3.2.3 M -> Start Freq

Set the start frequency of the analyzer to the frequency of the current marker.

- If Normal marker is selected, the start frequency will be set to the frequency of the current marker.
- If Delta, or Delta Pair marker is selected, the start frequency will be set to the frequency of the Delta Marker.
- The function is invalid in Zero span mode.

## 2.3.2.4 M -> Stop Freq

Set the stop frequency of the analyzer to the frequency of the current marker.

- If Normal marker is selected, the stop frequency will be set to the frequency of the current marker.
- If Delta, or Delta Pair marker is selected, the stop frequency will be set to the frequency of the Delta Marker.
- The function is invalid in Zero span mode.

### 2.3.2.5 M ->Ref Level

Set the reference level of the analyzer to the amplitude of the current marker.

- If Normal marker is selected, the reference level will be set to the amplitude of the current marker.
- If Delta, or Delta Pair marker is selected, the reference level will be set to the amplitude of the Delta Marker.

## 2.3.2.6 ΔM->Span

Set the span of the analyzer to the frequency difference between the two markers in Delta, or **Delta Pair** marker type.

- If **Normal** marker is selected, this function is invalid.
- The function is invalid in Zero span mode.

## 2.3.2.7 ΔM->CF

Set the center frequency of the analyzer to the frequency difference between the two markers in **Delta**, or **Delta Pair**, marker type.

- If **Normal** marker is selected, this function is invalid.
- The function is invalid in Zero span mode.

## 2.3.3 Marker Fn

Special marker functions including Noise Marker, N dB BW and Freq Counter.

## 2.3.3.1 Select Marker

Select one of the four markers (1, 2, 3, 4) and the default is Marker1.

### 2.3.3.2 Noise Marker

Execute the Noise marker function for the selected marker and read the noise power spectral density.

#### Key Points:

- If the current marker is "Off" in the Marker menu, pressing Noise Marker will first set it to Normal type automatically; then measure the average noise level at the marked point and normalize this value to 1 Hz bandwidth. During this process, certain compensation is always made on the basis of the detection and trace types. The measurement will be more precise if RMS Avg or Sample detection type is used.
- This function can be used for measuring the C/N ratio.

## 2.3.3.3 N dB BW

Enable the N dB BW measurement or set the value of N dB. The N dB BW denotes the frequency difference between two points that are located on both sides of the current marker and with N dB fall (N<0) or rise (N>0) in amplitude as shown in the figure on the next page.



Figure 2-8 N dB BW

#### Key Points:

- When the measurement starts, the analyzer will search for the two points which are located at both sides of the current point with N dB fall or rise in amplitude and display the frequency difference between the two points in the active function area. "----" would be displayed if the search fails.
- You can use the numeric keys, knob or direction keys to modify the value of N, for more details please refer to "Parameter Setting".

Parameter	Explanation
Default	-3dB
Range	-100dB ~ 100dB
Unit	dB
Knob Step	0.1
Direction Key Step	1dB

Table 2- 26 N dB Noise	Э
------------------------	---

## 2.3.3.4 Freq Counter

## Turn on or off the frequency counter.

- The function is invalid when selecting marker 2, 3, 4.
- If marker 1 is selected but no active, turning on the frequency counter will open marker 1 Normal marker automatically.
- The frequency readout is more accurate when the frequency counter is enabled.
- The frequency counter measures the frequency near the center frequency in Zero span mode.

## 2.3.3.5 Off

Turn off the noise marker enabled , N dB BW measurement or Frequency Counter, but not the marker itself.

## 2.3.3.6 Read Out

Select a desired readout type of the X-axis for the marker and different markers can use different readout types. This setting will change the readout type and affect the marker readings in the active function area and at the upper right corner of the screen, but will not change the actual value.

### 1. Frequency

In this type, Normal marker shows the absolute frequency; while Delta marker and Delta Pair marker show the frequency difference between the delta marker and reference marker. The default readout mode in non-zero span mode is "Frequency".

Note: This type is invalid in Zero span mode.

#### 2. Period

In this type, Normal marker shows the reciprocal of frequency; while Delta marker and Delta Pair marker show the reciprocal of frequency difference. When the frequency difference is zero, the reciprocal is infinite and 100 Ts is displayed.

Note: This type is invalid in Zero span mode.

### 3. ∆ Time

In this type, Normal marker shows the time difference between the marker and the start of the sweep; while Delta marker and Delta Pair marker show the sweep time difference between the delta marker and reference marker.

The default readout mode in Zero span mode is  $\Delta$  Time. 50 Spectrum Analyzer User Manual

## 2.3.4 Peak

Open the peak search setting menu and execute peak search.

## 2.3.4.1 Peak -> CF

Execute peak search and set the center frequency of the analyzer to the frequency of the peak.

## 2.3.4.2 Next Peak

Search for and mark the peak whose amplitude is closest to that of the current peak and which meets the peak search condition.

## 2.3.4.3 Next Left Peak

Search for and mark the nearest peak which is located at the left side of the current peak and meets the peak search condition.

## 2.3.4.4 Next Right Peak

Search for and mark the nearest peak which is located at the right side of the current peak and meets the peak search condition.

## 2.3.4.5 Peak Peak

Execute peak search and minimum search at the same time and mark the results with delta pair markers. Wherein, the result of peak search is marked with the delta marker and the result of minimum search is marked with the reference marker.

## 2.3.4.6 Count Peak

Enable or disable continuous peak search and the default is Off. When enabled, the system will always execute a peak search automatically after each sweep in order to track the signal under measurement.

## 2.3.4.7 Peak Table

Open the peak table (in the lower window) which lists the peaks (with frequency and amplitude) that meet the peak search condition. Up to 16 peaks can be displayed in the table.

## 2.3.4.8 Search Config

Define the conditions of peak search for various peak searches. A real peak should meet the requirements of both the "Peak Excursion" and "Peak Threshold".

#### 1. Peak Threshold

Assign a minimum for the peak amplitude. Peaks whose amplitudes are greater than the specified peak threshold are treated as real peaks.

Parameter	Explanation	
Default	-140dBm	
Range	-200dBm ~ 200dBm	
Unit	dBm	
Knob Step	1dBm	
Direction Key Step	5dBm	

Table 2- 27 Peak Threshold

#### 2. Peak Excursion

Set the excursion between the peak and the minimum amplitude on both sides of it. Peaks whose excursions are beyond the specified excursion are treated as real peaks.

28	Peak	Excursion
	28	28 Peak

Parameter	Explanation
Default	10dB
Range	0dB ~ 200dB
Unit	dB
Knob Step	1dB
Direction Key Step	5dB

#### 3. Peak Type

Set the peak search condition. The available options are Maximum and Minimum

## 2.4 Measurement

## 2.4.1 Meas

Provide measurement function, the screen will be divided into two parts, the above part is measure screen, displaying trace, the other part is used to display result of a measurement.

### 2.4.1.1 Channel Power

Measure the power and power density within the specified channel bandwidth. When this function is enabled, the span and resolution bandwidth are automatically adjusted to smaller values. Select **Channel Power** and press **Meas Setup** to set the corresponding parameters.

### 2.4.1.2 ACPR

Measure the powers of the main channel and adjacent channels as well as the power difference between the main channel and each of the adjacent channels. When this function is enabled, the span and resolution bandwidth of the analyzer are adjusted to smaller values automatically. Select **ACPR** and press **Meas Setup** to set the corresponding parameters.

### 2.4.1.3 Occupied BW

Integrate the power within the whole span and calculate the bandwidth occupied by this power according to the specified power ratio. The OBW function also indicates the difference (namely "Transmit Freq Error") between the center frequency of the channel under measurement and the center frequency of the analyzer. Select **Occupied BW** and press **Meas Setup** to set the corresponding parameters.

## 2.4.1.4 T-Power

The system enters zero span mode and calculates the power within the time domain. The types of powers available include Peak, Average and RMS. Select **T-Power** and press **Meas Setup** to set the corresponding parameters.

## 2.4.1.5 Meas Off

Turn off all the Meas function.

## 2.4.2 Meas setup



## 2.4.2.1 Channel Power

Figure 2-9 Channel Power

Measurement Results: channel power and power spectral density.

- Channel Power: power within the integration bandwidth.
- Power Spectral Density: power (in dBm/Hz) normalized to 1 Hz within the integration bandwidth.

Measurement Parameters: Center Freq, integration bandwidth , Span, Span power

#### 1. Center Freq

Sets the center frequency of display, this CF which is the same with the CF of the analyzer. Modifying this parameter will change the CF of the analyzer.

#### 2. Integration bandwidth

Set the frequency width of the channel to be tested and the power of the channel is the power integral within this bandwidth. You can use the numeric keys, knob or direction keys to modify this parameter.

Parameter	Explanation
Default	2 MHz
Range	100 Hz ~ Span
Unit	GHz,MHz,kHz,Hz
Knob Step	Integration BW/100, the minimum is 1 Hz
Direction Key Step	In 1-1.5-2-3-5-7.5 sequence

Table 2- 29 Integration BW

#### 3. Span

Set the frequency range of the channel. This span which is the same with the span of the analyzer is the frequency range of the sweep. Modifying this parameter will change the span of the analyzer.

- The channel power span is related to the integration bandwidth and the range available is from integration bandwidth to integration bandwidth x20.
- You can use the numeric keys, knob or direction keys to modify this parameter.

Parameter	Explanation
Default	3 MHz
Range	100 Hz ~ Span
Unit	GHz,MHz,kHz,Hz
Knob Step	Channel Power Span/100, the minimum is 1Hz
Direction Key Step	In 1-1.5-2-3-5-7.5 sequence

Table 2- 30 Channel Power Span for Chan Power Measurement

#### 4. Span Power

Set the integrated bandwidth to the sweep span of display. The channel power and power spectral density display on the screen simultaneously.

## 2.4.2.2 ACPR



Figure 2-10 ACPR

Adjacent Channel Power Measurement: Main CH Power, Left channel power and Right channel power.

- Main CH Power: display the power within the bandwidth of the main power
- Left channel power : display the power of left channel and the power difference between the left channel and the main channel (in dBc)
- Right channel power: display the power of the right channel and the power difference between the right channel and the main channel (in dBc)

Measurement parameter: center frequency, main channel bandwidth, adjacent channel bandwidth and channel spacing

#### 1. Center Frequency

Sets the center frequency of display, this CF which is the same with the CF of the analyzer. Modifying this parameter will change the CF of the analyzer.

#### 2. Main channel bandwidth

Set the bandwidth of the main channel and the power of the main channel is the power integral within this bandwidth. You can use the numeric keys, knob and direction keys to modify this parameter.

Parameter	Explanation
Default	2 MHz
Range	100 Hz ~ Sweep Span
Unit	GHz,MHz,kHz,Hz
Knob Step	Integration BW /100, the minimum is 1 Hz
Direction Key Step	In 1-1.5-2-3-5-7.5 Sequence

Table 2-31 Main channel bandwidth

#### 3. Adjacent channel bandwidth

Set the frequency width of the adjacent channels.

- The adjacent channel bandwidth is related to the main channel bandwidth and the range available is from main channel bandwidth/20 to main channel bandwidth ×20.
- You can use the numeric keys, knob or direction keys to modify this parameter.

Parameter	Explanation
Default	2 MHz
Range	100 Hz ~ Sweep Span
Unit	GHz,MHz,kHz,Hz
Knob Step	Integration BW /100, the minimum is 1 Hz
Direction Key Step	In 1-1.5-2-3-5-7.5 Sequence

Table 2- 32 adjacent channel bandwidth

#### 4. Adjacent Channel space

Set the difference between the center frequency of the main channel and the center frequency of the adjacent channels.

- Adjusting this parameter will also adjust the distance between the upper/lower channel and the main channel.
- You can use the numeric keys, knob or direction keys to modify this parameter.

Parameter	Explanation
Default	2 MHz
Range	33 Hz ~ full span
Unit	GHz,MHz,kHz,Hz
Knob Step	Integration BW /100, the minimum is 1 Hz
Direction Key Step	In 1-1.5-2-3-5-7.5 Sequence

Table 2-33 Adjacent channel space

## 2.4.2.3 OBW



Figure 2-11 OBW

OBW measurement: occupied bandwidth and transmit frequency error.

- Occupied Bandwidth: integrate the power within the whole span and then calculate the bandwidth occupied by the power according to the specified power ratio.
- Transmit Frequency Error: difference between the center frequency of the channel and the center frequency of the analyzer.



## 2.4.2.4 T-Power

Figure 2-12 T-Power

T-Power: namely the power of the signal from the start line to the stop line.

Measurement Parameter: center frequency, start line, stop line

#### 1. Center Frequency

Sets the center frequency of display, this CF which is the same with the CF of the analyzer. Modifying this parameter will change the CF of the analyzer.

#### 2. Start line

Set the left margin (in time unit) of T-Power measurement. The data calculated under this measurement is between the start line and stop line. You can use the numeric keys, knob or direction keys to modify this parameter.

Explanation	
1ms	
0 s ~ stop line	
ks,s,ms,us,ns,ps	
Sweep time/751	
In 1-1.5-2-3-5-7.5 Sequence	

#### Table 2- 34 start line

#### 3. Stop line

Set the right margin (in time unit) of T-Power measurement. The data calculated under this measurement is between the start line and stop line. You can use the numeric keys, knob or direction keys to modify this parameter.

Parameter	Explanation
Default	24.032ms
Range	Start line ~ sweep time
Unit	ks,s,ms,us,ns,ps
Knob Step	Sweep time /751
Direction Key Step	In 1-1.5-2-3-5-7.5 Sequence

# 2.5 System

## 2.5.1 System

Set the system parameters.

## 2.5.1.1 Language

The spectrum Analyzer supports multi-language menu, Chinese and English build-in help and popup messages.

Press this key to select the desired display language.

## 2.5.1.2 Power On/Preset

#### 1. Power On/Preset

Set the power on setting to" factory (default)", "Last" or one of "user".

Set the preset type to factory (default), "Last" or one of "User".

#### Last

When "Last" is selected, settings before the last power-off would be recalled automatically at power on.

#### User

Select user-defined configuration from "user1" to "user6"

If power on set to user, the device will recall the specified configuration after power on and press Preset at the front panel under any operation interface will recall the specified preset type.

### 2. USER-DEFINED

Save the current instrument setting as user-defined setting into the internal non-volatile memory. You can store and name up to 6 system states, and name every STA file.

### 3. Factory

When "factory" is selected, the device will recall the initial config.

## 2.5.1.3 Interface Config

The spectrum Analyzer support communications through LAN, USB as standard interface.

#### 1. LAN

Config or reset corresponding parameters of LAN.

## 2.5.1.4 Calibration

### Auto Cal

When "Auto Cal" open, spectrum Analyzer will process self-calibration regularly. Within half an hour after power-on, the device executes a self-calibration every 10 minutes.

## 2.5.1.5 System Info

#### 1. System Info

- Product Model , Serial and HOST ID
- Software Version and Hardware Version
- Calibration Date
- Option Information
- 2. Firmware Update

Update firmware

## 2.5.1.6 Data and Time

The system time is displayed in "ymd", "mdy", "dmy" format in user interface.

## 2.5.1.7 Self Test

#### Screen Test

Test whether the screen has a dot defect using five colors: White, Red, Green, Blue and Black. Press any key to switch the screen color and exit the test.

#### **Keyboard Test**

Enter the keyboard test interface. Press the function keys at the front panel one by one and observe whether the corresponding key be checked. If not, an error may have occurred in that key. To exit the test, press "<-" four times.

#### LCD Test

If the keys at the front panel are transparent, when the key is pressed, the corresponding backlight will turn on when testing it.

## 2.5.2 Display

Control the screen display of the analyzer, such as setting the display grid brightness.

#### 1. Grid brightness

Control the display grid brightness.

Parameter	Explanation	
Default	30%	
Range	0 ~ 100%	
Unit	None	
Knob Step	1%	
Direction Key Step	1%	

#### Table 2- 36 Grid brightness

#### 2. Display Line

Open or Close Display Line or move the location.

## 2.5.3 File

## 2.5.3.1 Browser

Browser type including "Dir" and "File",

Dir: when selected, use the knob or direction keys to browser directory in system File: when selected, use the knob or direction keys to switch among files or folders under the current directory.

## 2.5.3.2 Open/Load

Open the current folder or load current file

## 2.5.3.3 Type

user can define the file type be browsed and saved, included "all type", "STA", "SET", "TRC", "COR", "LIM", "BMP", CSV".

## 2.5.3.4 Save

Save file in current directory, the file type is set in "Type"

## 2.5.3.5 Create Folder

Create a new folder in current directory.

## 2.5.3.6 Delete

Delete selected file or directory.

### 2.5.3.7 Rename

Rename the selected file or folder.

## 2.5.3.8 Operate

Open/Load: Open the selected folder or directory, Load the selected file Cut : Cut the Selected file or folder, and delete the primary one after paste Copy : Copy the Selected file or folder for paste. Paste : Paste the file cut or copied before into the current. Delete : Delete selected file or directory.

# 2.6 Shortcut Key

## 2.6.1 Preset

Recall the preset setting and restore the analyzer to a specified status.

- Press System ->Pwr On/Preset .Preset to select "Def", "Last" or "User".
- Press Preset to load the factory settings listed in the following table (except items marked with "\*\*") or User-defined settings.

Parameter	Default
Frequency	
Center Freq	1.6 GHz (or 1.5 GHz, 1.05 GHz, 900 MHz, 750 MHz, 500 MHz)
Start Freq	0 Hz
Stop Freq	3.2GHz (or 3.0 GHz, 2.1 GHz, 1.8 GHz, 1.5 GHz, 1.0 GHz)
Freq Step	Auto, 320MHz (or 300MHz, 210MHz, 180MHz, 150MHz, 100MHz)
Span	
Span	3.2GHz (or 3.0 GHz, 2.1 GHz, 1.8 GHz, 1.5 GHz ,1.0 GHz)
Amplitude	
Ref Level	0 dBm
Attenuator	Auto, 20 dB
Preamp	Off
Units	dBm
Scale/Div	10 dB
Scale Type	Log
Ref Offset	0 dBm
Corrections	Off
BW	
RBW	Auto, 1MHz
VBW	Auto, 1MHz
VBW/RBW	1
Avg Type	Log Pwr
Sweep	
Sweep Time	Auto, 312.416 ms (or 312.416 ms, 216.288 ms, 192.256 ms, 168.224
	ms, 120.160 ms)
Sweep Rule	Speed
Sweep	Continue
Sweep Mode	Auto
Numbers	1
Trig	
Trigger Type	Free Run

Table 2-60 Factory Settings

I

## **Scientific**

Video Trigger	0 dBm	
External Trigger	Rasing	
TG	rasing	
TG	Off	
TG Level	0 dBm	
TG Lvl Offset	0 dB	
Normalize	Off	
Norm Ref Lvl	0 dB	
Norm Ref Pos	100%	
Ref Trace	Blank	
Trace		
Select Trace	Α	
Trace Type of Trace A	Clear Write	
Avg Times	100	
Variable X	A	
Variable Y	В	
Constant	0 dB	
Output Z	С	
Math Type	Off	
Detect		
Select Trace	Α	
Detect Type of Trace A	Pos Peak	
Limit		
Limit1	Off, Limit Upper, 0 dBm	
Limit2	Off, Limit Lower, -100 dBm	
Test	Stop	
Fail to stop	Off	
Buzzer	Off	
X Axis	Freq	
Demod		
Demod Mode	Close	
Earphone	Off	
Volume	6	
Demod Time	5 ms	
Marker		
Select Marker	1	
Select Trace	A	
Marker Type	Normal	
Delta Pair	Delta	
Relative To	Off	
Marker Table	Off	
Marker Fctn		
Select Marker	1	

Marker Fn	Off
N dB BW	-3 dB
Read Out	Frequency
Peak	
Cont Peak	Off
Peak Table	Off
Peak Threshold	-140 dBm
Peak Excursion	10 dB
Peak Type	Max
Mode	
Mode	Spec Analyzer
Measure	
Meas Type	Off
Measure Setup	
Channel Power	
Center Freq	1.6 GHz (or 1.5 GHz, 1.05 GHz, 900 MHz, 750 MHz, 500 MHz)
Integration BW	2 MHz
Span	3.2GHz (or 3.0 GHz,2.1 GHz,1.8 GHz,1.5 GHz,1.0 GHz)
ACPR	
Center Freq	1.6 GHz (or 1.5 GHz, 1.05 GHz, 900 MHz, 750 MHz, 500 MHz)
Main Channel	1 MHz
Adjacent Chn	1 MHz
Adj Chn Space	3 MHz
Occupied BW	
Method	%
dBc	26
%	99
T-Power	
Center Freq	1.6 GHz (or 1.5 GHz, 1.05 GHz, 900 MHz, 750 MHz, 500 MHz)
Start Line	0 s
Stop Line	20 ms
System**	
Language	English
Power On	Def
Preset	Def
IP Config	Static
Auto Cal	Close
Tine Date	On
Set Format	ymd

## 2.6.2 Couple

Set related parameters according to the coupling relationship.

Auto all : Set Related parameters automatically according to the coupling relationship.

## 1. RBW

RBW have couple relationship with span. Please refer to the introduction of the "Resolution Bandwidth"

### 2. VBW

VBW have coupling relationship with VBW. Please refer to the introduction of "VBW".

#### 3. Attenuation

Input attenuation have coupling relation ship with Ref Level, preamp. Please refer to introduction of the "amplitude".

### 4. CF step

CF step have coupling relationship with RBW at the zero span, When in none-zero mode, CF step have coupling relationship with Span. please refer to the introduction of the "Freq Step".

#### 5. Sweep time

Sweep time have coupling relationship with RBW, VBW and span. Please refer to the introduction of "Sweep Time".

## 2.6.3 Help

After press "Help", press any key to help information.

## 2.6.4 Save

Quick saving a file.

# Chapter 3 General Inspection and Troubleshooting

# 3.1 General Inspection

#### 1. Inspect the shipping container

Keep the damaged shipping container or cushioning material until the contents of the shipment have been completely checked and the instrument has passed both electrical and mechanical tests.

The consigner or carrier will be responsible for damages to the instrument resulting from shipment. We will not provide free maintenance or replacement.

2. Inspect the instrument

If the instrument is found to be damaged, defective or fails in electrical or mechanical tests, please contact your sales representative.

#### 3. Check the accessories

Please check the accessories according to the packing list. If the accessories are incomplete or damaged, please contact your sales representative.

# 3.2 Troubleshooting

The commonly encountered failures and their solutions are listed below. When you encounter those problems, please solve them following the corresponding steps. If the problem remains still, please contact your sales representative. and provide your device information (**System**->**System Info**).

### 1. The screen is still dark (no display) after power on:

- (1) Check whether the fan is running:
- If yes, the connection of the internal screen cable may be loose.
- If not, the instrument has failed to start up and please refer to step (2). (2)

Check the power:

- Check whether the power supply has been connected correctly and the power switch has been turned on.
- Check whether the power fuse is burned. If a new fuse needs to be installed, please use a specified fuse

### 2. The key is unresponsive or gives a wrong response:

(1) Press all the keys at the front panel to check if all of them are normal after power on. (2)

- Press System ->Self-Test ->Key Test to check if all the keys are working properly.
- (3) If a key is not working, the numeric keyboard connection might be loose or the numeric keyboard is broken. Do not disassemble the instrument by yourself and contact your sales representative.

## Scientific

#### 3. The spectrum lines on the screen do not update for a long period of time:

- (1) Check whether the screen is locked; if so, press **Esc** to unlock it.
- (2) Verify whether all the trigger conditions have been met and whether there is a valid trigger signal.
- (3) Check whether the analyzer is in single sweep.
- (4) Check whether the current sweep time is too long.

#### 4. Wrong measurement results or poor precision:

To calculate the system errors and check the measurement results and precision, refer to the introductions in "**Specifications**". To reach these specifications, please:

(1) Check whether all the external devices are successfully connected and are working normally.

(2) Get some knowledge of the signal under measurement and set appropriate instrument parameters.

(3) Make measurements under proper conditions; for example, warm-up the instrument appropriately and operate the instrument under the specified environment temperature. (4) Calibrate the instrument regularly to reduce or avoid errors that might occur over time.

 If you need a specific calibration after the stated calibration period, contact your sales representative.or get paid service from authorized measurement agencies.

The analyzer provides auto calibration function. If required, press
System->Calibration->Auto Cal and select "Open". The instrument will perform self-calibration regularly.

#### 5. Pop-up Message:

The instrument may display prompt messages, error messages or state messages according to the current working status. These messages are displayed to help you to use the instrument correctly and are not instrument failures.

# **Chapter 4 Service and Support**

No user serviceable parts are inside the instrument, should it become necessary to send back the instrument to factory for service, please observe the following procedure.

- 1. Before dispatching the instrument please write to us giving full details of the fault noticed, model number and serial number.
- 2. After receipt of your letter our service department will advise you whether it is necessary to send the instrument back to us for repairs or the adjustment is possible in your premises.
- Dispatch the instrument to us (only on the receipt of our advice) at our factory address, securely packed in original packing, duly insured and freight paid along with accessories and a copy of the fault details noticed.